

# **clean coat**

## **HIGH TEMPERATURE ANTI-STATIC IRONER LUBRICANT**

### **INSTRUCTIONS FOR USE**

Spread CLEANCOAT across an applicator cloth in a strip approximately 40 cm wide. Make sure the cloth is saturated. Run the cloth through the hot ironer at its lowest speed with the extract off. Repeat at regular intervals, at least before each break. Renew the CLEANCOAT at least twice each week. Use CLEANPASTE to remove dirt and deposits.