

clean paste

CLEANER FOR IRONERS

Non abrasive, developed to remove all alkaline and starch residues from the ironer's chest and bed.

INSTRUCTIONS FOR USE

Run the ironer at full temperature and at its lowest speed, with the extract fans turned off. Spread CLEANPASTE across an Cleanpaste applicator cloth in a strip approximately 40 cm (15 ins) wide. Make sure the cloth is saturated. Run the cloth through the ironer twice, followed by a succession of damp sheets in order to remove dirt. After cleaning, use CLEANCOAT lubricant.